

## A-13007-Q12 Installation Instructions

- 1) Remove any existing socket from the center of your reflector.
- 2) Punch, drill or file the existing hole to 1 inch in diameter.
- 3) Install the new Quartz Halogen socket with the press nut on the back side. Note: The small dot on the socket is "UP".
- 4) The drawing below shows the Quartz Halogen bulb as seen from the back. Make connections as shown.
- 5) After installation is complete, clean the Quartz Halogen bulb glass with the enclosed alcohol wipe. Do not touch the bulb with bare fingers after the bulb is cleaned.

