
## A-47301 Rain Gutter

Before cutting or mounting, you must put a bend in gutters where the bend down at the rear of the car.

Before bending, place a layer of wax paper between the tack piece and the drip edge piece. The two pieces must

be bent together and the must have a layer of wax paper between them. If you don't use the wax paper, you will distort the gutters when you separate them after bending.



Tack tacking piece of gutters to top and snap drip edge in place. It is a good idea to put a small sheet metal screw at each end of the gutters. Put screw right at the edge so drip gutter tips will hide the screws. You're done!!

